

# Scooter av-2: Remedy against the difficulty of taking the head assembly off

~Take the pressure equilibrium by the operation of the relief valve.~

1 The entire head assembly.



2 Remove one side of saddle panel on which no switch is located.



3 There is a small relief valve in the back of small hole.



4 Enlarged view.



5 Prepare a precision screwdriver, etc.  
(Do not use sharp tip one)



6 Insert the tip of the precision screwdriver into the small hole until the tip touches the relief valve.



7 Move the precision screwdriver sideways to slide the relief valve. By this operation, air gets into the head assembly to take the pressure equilibrium.

